



3間タイプ





盆踊りやぐら 3.0K
[コード] 12011-30



2間半タイプ



盆踊りやぐら 2.5K
[コード] 12011-25



1・2間タイプ



盆踊りやぐら 1.2K
[コード] 12011-12

